

HAYMAN REESE
PART No: **02936RW**
MERCEDES BENZ M CLASS 10/06 ON

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT ALL INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT
PLACE THESE INSTRUCTIONS IN THE VEHICLE'S GLOVEBOX AFTER INSTALLATION IS COMPLETE



Installation Time: Approx 130 Mins

Towbar Installation Instructions

Towbar capacity

MERCEDES BENZ M CLASS 10/06-ON

Part Number 02936RW

Max Towing Braked 3500 kg

Max Static Ball Load 350 kg

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

HAYMAN REESE

PART No: 02936RW

MERCEDES BENZ M CLASS 10/06 ON

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT ALL INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT
PLACE THESE INSTRUCTIONS IN THE VEHICLE'S GLOVEBOX AFTER INSTALLATION IS COMPLETE

Warning:

1. Do not, drill, cut, weld or otherwise modify the towbar.
2. If you are using electric welding on a motor vehicle, **always** check that the vehicle is not equipped with electronic engine or instrument management equipment. Failure to do so could **destroy** any onboard computers. If in doubt, check with the vehicle's manufacturer.
1. **General:** Ensure all hardware items have been included refer to assembly diagram.
2. It is recommended that the instructions are read through and completely understood before making any attempt to fit this product.
3. Be wary of any changes to vehicle designs or other accessories that may conflict with the installation of this product.
4. Before drilling ensure that the area is clear of fuel, electrical & other components.
5. All holes drilled into the body panels shall have all burrs & swarf removed then coated with a suitable rust preventative paint.
6. The high tensile fasteners supplied with this product were used to achieve the specified rating. If replacement is required ensure that fasteners of the same rating & quality are used. Contact an authorised **Hayman Reese** dealer if further information is required.
7. Ensure that all hardware is fastened to torque list below check fasteners on regular basis.
8. Towbar load rating sticker provided with this product shall be conspicuously located on inside rear end of the driver's door. **(See diagram below).**
9. Hayman Reese recommends that you check your tow ball to ensure that it complies with the Australian standards **AS 4177.2**.
10. **PLEASE NOTE:** It is advised to remove your lug or tbn when not actually towing so as to produce a clear view of the vehicles registration plate if obscured, and to also provide maximum available departure angle.
11. Pull Pin must be fit in down position.


Tow bar Maintenance and Care.

Hayman Reese recommends that bolt torque's, as listed below, are routinely and regularly inspected and checked for correct tension. Replace any worn or defective parts.

We recommended to remove Tow Ball Mounts (TBM's, tongues or lugs) when not being used for any considerable length of time.

So as to avoid injury, when not towing it is suggested that the tongue, Pull Pin and R-clip are removed then stored in a safe, clean and dry place, away from excessive moisture.

Hitch Pull Pins and spring "R" clips are regularly checked for proper installation. Replace any worn or defective parts.



Place load rating sticker
inside driver's door here

RECOMMENDED ASSEMBLY TORQUE LISTING

Diameter Grade 8.8 Bolt

M6	9.5 Nm
M8	21.7 Nm
M10	43.4 Nm
M12	77.3 Nm
M14	146 Nm
M16	189.8 Nm

FOR TOWING PURPOSES ONLY

For towing capacity details please refer to vehicle owner's manual or to the manufacturer. Overloading can void your warranties.


HAYMAN REESE

PART No: 02936RW


MERCEDES BENZ M CLASS 10/06 ON

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT ALL INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT
PLACE THESE INSTRUCTIONS IN THE VEHICLE'S GLOVEBOX AFTER INSTALLATION IS COMPLETE



QTY.	DESCRIPTION	ITEM NO.
1	TOWBAR WELDED ASSEMBLY	1
1	LHS CHASSIS INSERT	2
1	RHS CHASSIS INSERT	3
1	SUPPORT STEP	4
1	CLASS 4 TBM	5
1	LH SUPPORT BRACKET	6
1	RH SUPPORT BRACKET	7
4	SPACER TUBE LONG	8
4	SPACER TUBE SHORT	9
6	PACKER - 8mm	10
2	PACKER - 6mm	11
2	PLASTIC END CAP	12
1	BUMPER TRIM PINCH WELD 400mm	13
24	WASHER FT M10 x25.4	14
11	HEX NUTM10 x 1.5	15
3	BOLT M10-1.5x 35mm	16
1	BOLT M10-1.5 x 25	17
12	BOLT M10-1.5x35mm	18
4	BOLT M8 x 25	19
8	M12 x 1.25 HEX NUT	20
4	M8 - 1.25 NUT	21
12	SPRING WASHER M10 x 3.5 x 2.2	22
8	WSHR SPRING FT SEC M12x4.0x2.0mm	23
8	WSHR FT M8x17x1.20 Z/P	24
4	WSHR SPRING FT SEC M8x3.0x2.0mm	25
8	BOLT M12-1.25x110 GR8.8	26
16	WASHER M12x28.8x3mm	27
1	PULL PIN	28
1	SPRING COTTER PIN ASSY	29
1	HITCH BOX COLLAR COVER	30



HAYMAN REESE


PART No: 02936RW

MERCEDES BENZ M CLASS 10/06 ON


INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT ALL INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT
PLACE THESE INSTRUCTIONS IN THE VEHICLE'S GLOVEBOX AFTER INSTALLATION IS COMPLETE


1. Remove the 3 Scrivets and 2 Bolts (or 5 Scrivets on vehicles without mudguard) which holding the Mudflaps to the Bumper.



2. If mudflap is fitted, remove most bolts which holding the mudflap bracket and wheel arch trim of the vehicle.



3. Use a screw driver to pull back the wheel arch trim and remove most bolts which holding the bumper of the vehicle.



HAYMAN REESE

PART No: 02936RW


MERCEDES BENZ M CLASS 10/06 ON

INSTALLATION INSTRUCTIONS


PLEASE ENSURE THAT ALL INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

PLACE THESE INSTRUCTIONS IN THE VEHICLE'S GLOVEBOX AFTER INSTALLATION IS COMPLETE


4. Remove the four Bolts which holding the bottom of the Bumper.



5. Remove the floor panel and also the LHS & RHS panels.



6. Remove the spare tyre and the Jack Assembly from rear tyre well.



HAYMAN REESE

PART No: 02936RW



MERCEDES BENZ M CLASS 10/06 ON

INSTALLATION INSTRUCTIONS



PLEASE ENSURE THAT ALL INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT
PLACE THESE INSTRUCTIONS IN THE VEHICLE'S GLOVEBOX AFTER INSTALLATION IS COMPLETE

7. To post 2012 models, remove both LH and RH light assemblies to provide better access to remove Bumper. Remove Bumper by firmly pulling outwards to detach from clips.


Note: Disconnect rear parking sensor plug if fitted.



8. To pre 2012 models remove both LH and RH Bolts which holding the bumper of the vehicle. Remove the two Nuts which holding the bumper to the vehicle and firmly pull on bumper to remove.



9. Remove the four Nuts holding the rear Impact Beam which inside of the vehicle and the four Nuts underneath of the vehicle. Also remove the Fuel Tank Cover Bracket Bolts and Muffler Heat Shield Bolts.



HAYMAN REESE

PART No: 02936RW


MERCEDES BENZ M CLASS 10/06 ON

INSTALLATION INSTRUCTIONS


PLEASE ENSURE THAT ALL INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

PLACE THESE INSTRUCTIONS IN THE VEHICLE'S GLOVEBOX AFTER INSTALLATION IS COMPLETE

10. Locate Chassis Inserts to vehicle. Loosely secure both forward mounts using M10x35 Bolts with Spring and Flat Washers.




11. Loosely secure the chassis inserts to the rear panel on the vehicle using M10x35 Bolts with Spring, Flat Washers and M10 Nuts.



12. To post 2012 models, secure supplied Bracket which mount on Chassis Inserts plate to fuel tank cover bracket by using supplied M10x35 bolts with Spring, Flat Washers and M10 nuts.

To pre 2012 models disregard this step and supplied brackets.



HAYMAN REESE

PART No: 02936RW


MERCEDES BENZ M CLASS 10/06 ON

INSTALLATION INSTRUCTIONS


PLEASE ENSURE THAT ALL INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT
PLACE THESE INSTRUCTIONS IN THE VEHICLE'S GLOVEBOX AFTER INSTALLATION IS COMPLETE

- 13.** Insert spacer tubes into top and sides of the chassis inserts.
Fit main towbar according to diagram on Page 3.

Torque all fasteners to specification shown in Page 2.



- 14.** Cut 80mm wide 120mm long from the bottom centre of the bumper bar and fit the bumper trim provided over the cut.
Refit bumper skin back on vehicle and all associated panels and parts.



HAYMAN REESE

PART No: 100179-WL

MERCEDES E-CLASS & MERCEDES ML250 / ML350-CLASS (2011 - Onwards)

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

Wiring Loom Installation Instructions

MERCEDES E-CLASS & MERCEDES ML250 / ML350-CLASS (2011 - Onwards)

Part No: 100179-WL
ECU: 04826

Mercedes E-Class Tail Harness Length Required: 1200mm
Mercedes ML250/ML350 Tail Harness Length Required: 1800mm

MERCEDES E - CLASS - Pages: 2-7
MERCEDES ML250 / ML350 - CLASS - Pages: 8-13

Wiring Loom Installation Time: Approx.30 minutes

Issue Date 07/09/12

Page 1

Part No: 100179-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE

PART No: 100179-WL

MERCEDES E-CLASS & MERCEDES ML250 / ML350-CLASS (2011 - Onwards)

INSTALLATION INSTRUCTIONS


PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

The following steps are for Mercedes E-class models only. For Mercedes ML250/ML350-Class models, please proceed to step 8.

1. In the luggage compartment, remove the floor carpet cover (1).
2. Fold the rear seats (2) forwards.
3. Remove the RHS boot hinge cover trim (3).
4. From outside the vehicle, remove the rear bumper (4).



5. Back inside the luggage compartment, remove the rear trim (1).



6. Remove the LHS access panel cover (1).



Issue Date 07/09/12

Page 2

Part No: 100179-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

HAYMAN REESE


PART No: 100179-WL

MERCEDES E-CLASS & MERCEDES ML250 / ML350-CLASS (2011 - Onwards)

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT


7. Remove RHS access panel covers (1).
8. Remove the RHS side trim (2) by first removing any fasteners.



9. From outside the vehicle, remove the RHS rear grommet (1).
10. Drill out the grommet hole to $\text{\O}30\text{mm}$.
11. File any rough or sharp edges and spray on rust inhibitor.



12. Inside the luggage compartment, disconnect the LHS tail light connector (1).
13. Patch in the trailer harness (P/No: 100179-WL) mating connectors.



Issue Date 07/09/12

Page 3

Part No: 100179-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE


PART No: 100179-WL

MERCEDES E-CLASS & MERCEDES ML250 / ML350-CLASS (2011 - Onwards)


INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

14. Route the trailer harness (1) from the LHS, along the rear of the vehicle and towards the RHS.




15. Disconnect the RHS tail light connector (1).
16. Patch in the trailer harness mating connectors.



17. Locate the wiring loom (1) behind the RHS boot hinge.
18. Cut open the wiring loom (1) and locate the vehicle 'GREY/BLUE' reverse wire (2).
19. Following the table below, connect the ezy tap (3) to the harness wire (2) and then connect the trailer harness terminal (4) to the corresponding wire (2).

Function	Trailer Patch	Vehicle Connector
REVERSE	BLACK / WHITE	GREY / BLUE



Issue Date 07/09/12

Page 4

Part No: 100179-WL

Hayman Reese (Cequent)

PO Box 4050, Dandenong South VIC 3164

Phone 1800 812 017 Email info@haymanreese.com.au

HAYMAN REESE


PART No: 100179-WL

MERCEDES E-CLASS & MERCEDES ML250 / ML350-CLASS (2011 - Onwards)


INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

20. Locate the vacant slot (1) in the vehicle fuse panel, just below the vehicle 20-amp fuse.
21. Insert the supplied 30-amp (2) fuse into the upper slot of the add-a-fuse harness (3).
22. Connect the add-a-fuse harness (3) into the vacant slot (1) on the fuse panel.
23. Connect the trailer harness 1-way connector (4) to the add-a-fuse harness (3) mating connector.



24. Connect the trailer harness 12-way connector (1) into the ECU (2).



25. Using double sided tape, adhere the ECU to the vehicle sheet metal area (1) as shown.



Issue Date 07/09/12

Page 5

Part No: 100179-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE


PART No: 100179-WL

MERCEDES E-CLASS & MERCEDES ML250 / ML350-CLASS (2011 - Onwards)

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT


26. Connect the trailer harness ground ring terminal (1) to the vehicle grounding point (2).



27. Mount the trailer socket (1) to the towbar mounting bracket using M4 fasteners (not supplied).
28. Route the tail harness (tail length 1200mm) (2) into the luggage compartment, through the previously drilled out grommet hole.
29. Ensure the tail harness grommet is seated correctly and secure in place using a cable tie (not supplied).



30. Connect the tail harness (tail length 1200mm) 8-way connector (1) to the trailer harness mating 8-way connector (2).



Issue Date 07/09/12

Page 6

Part No: 100179-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE

PART No: 100179-WL

MERCEDES E-CLASS & MERCEDES ML250 / ML350-CLASS (2011 - Onwards)

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

- | | |
|---|--|
| <ol style="list-style-type: none">31. Test the trailer harness function using a light board or multimeter.32. Secure all harnesses using cables ties (not supplied).33. Re-fit all removed parts and secure all fasteners, ensuring there are no squeaks or rattles.34. Place instructions in glove box after fitment. | |
|---|--|

Issue Date 07/09/12

Page 7

Part No: 100179-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE

PART No: 100179-WL

MERCEDES E-CLASS & MERCEDES ML250 / ML350-CLASS (2011 - Onwards)

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

The following steps are for Mercedes ML250/ML350-Class vehicle models. For Mercedes E-Class models, please refer to page 2.


1. In the luggage compartment, remove the plastic cover (1).
2. Remove the parcel shelf support (2).



3. Remove the carpet cover (1).



4. Remove both the LHS & RHS storage trays (1) by first removing the two clips (2).
5. Remove both the LHS & RHS access panels (3).



Issue Date 07/09/12

Page 8

Part No: 100179-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE

PART No: 100179-WL

MERCEDES E-CLASS & MERCEDES ML250 / ML350-CLASS (2011 - Onwards)


INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT


6. Remove the rear luggage compartment trim (1) by pulling in an upwards direction.



7. On the RHS of the luggage compartment, remove the parcel shelf screw (1) and the three cargo hooks (2).
8. Whilst dislodging the RHS luggage compartment trim (3), disconnect the 2-way connector (4).
9. Remove the RHS luggage compartment (3) from the vehicle.



10. On the LHS of the luggage compartment, disconnect the vehicle tail light assembly connectors (1) and connect the trailer patch (100179-WL) connectors (2) in between.



Issue Date 07/09/12

Page 9

Part No: 100179-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE

PART No: 100179-WL

MERCEDES E-CLASS & MERCEDES ML250 / ML350-CLASS (2011 - Onwards)


INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

11. Route the trailer harness (1) along the rear of the luggage compartment towards the RHS of the vehicle.




12. On the RHS of the luggage compartment, disconnect the tail light assembly connectors (1) and connect the trailer patch connectors (2) in between.



13. Locate the 'BLACK / YELLOW' vehicle wire (1) in the location shown.

14. Following the table below, connect the ezy tap (2) to the harness wire (1) and then connect the trailer harness terminal (3) to the ezy-tap (2).

Function	Trailer Patch	Vehicle Connector
REVERSE	BLACK / WHITE	YELLOW / BLACK



Issue Date 07/09/12

Page 10

Part No: 100179-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE


PART No: 100179-WL

MERCEDES E-CLASS & MERCEDES ML250 / ML350-CLASS (2011 - Onwards)


INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT


15. Secure the ground ring terminal (1) to the vehicle grounding point (2) in the location shown.



16. Connect the trailer harness 12-way connector (1) into the ECU (2).



17. Secure the ECU to the vehicle by using double sided adhesive tape.



Issue Date 07/09/12

Page 11

Part No: 100179-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE


PART No: 100179-WL

MERCEDES E-CLASS & MERCEDES ML250 / ML350-CLASS (2011 - Onwards)

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT


18. Locate the 10-amp (1) fuse as shown and remove.
19. Insert the supplied 20-amp fuse (2) into the upper slot of the add-a-fuse (3) and insert the previously removed 10-amp fuse (1) into the bottom slot of the add-a-fuse (3).
20. Plug the add-a-fuse (3) into the previously removed 10-amp fuse slot.
21. Connect the power patch 1-way connector (4) into the add-a-fuse harness mating connector (5).



22. Mount the trailer socket (1) to the towbar mounting bracket using M4 fasteners (not supplied).
23. Route the tail harness (tail length 1200mm) (2) into the luggage compartment, through the existing grommet hole.
24. Ensure the tail harness grommet is seated correctly and secure in place using a cable tie (not supplied).



25. Connect the tail harness (tail length 1200mm) 8-way connector (1) to the trailer harness mating 8-way connector (2).



Issue Date 07/09/12

Page 12

Part No: 100179-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au



HAYMAN REESE

PART No: 100179-WL

MERCEDES E-CLASS & MERCEDES ML250 / ML350-CLASS (2011 - Onwards)

INSTALLATION INSTRUCTIONS

PLEASE ENSURE THAT INSTRUCTIONS ARE UNDERSTOOD PRIOR TO FITMENT

- | | |
|---|--|
| <ol style="list-style-type: none">26. Test the trailer harness function using a light board or multimeter.27. Secure all harnesses using cables ties (not supplied).28. Re-fit all removed parts and secure all fasteners, ensuring there are no squeaks or rattles.29. Place instructions in glove box after fitment. | |
|---|--|

Issue Date 07/09/12

Page 13

Part No: 100179-WL

Hayman Reese (Cequent)
PO Box 4050, Dandenong South VIC 3164
Phone 1800 812 017 Email info@haymanreese.com.au

www.haymanreese.com.au

